







MonuMount Assembly Instructions

1. Unpack all your sign components from the skid.
2. Start by leveling the ground where you are going to place your sign monument base. We recommend buying some smooth driveway pavers (12"x12" sections) and place them on your smooth/leveled ground. This gives you a solid base to sit your base on.
3. Pre Dig 2 holes in the ground, (using the measurement/distance of the square holes that are in the "monument base top" as a guide (shown in steps #5 and #6 below)). The hole depth should be below frost line in your area (we recommend a 32"- 42" inch deep hole).
4. Purchase two treated wood 4x4's from your local lumber yard. These will be buried in the ground and extend up through the base and into the hollow PVC post sleeves mounted to the side of your sign faces.

		
<p>1. Dig two holes (spacing is determined by existing holes in monument base cap). Mount two 4x4 treated posts in the holes using concrete.</p>	<p>2. Assemble the monument base by sliding the endpost assemblies down onto the tabs of the front and back faces and slide in toward the middle and settle the assembly on the tab until it is even with the bottom of the monument faces.</p>	<p>3. The monument top will slide over the treated wood 4x4 posts that are already mounted in the ground (see step 4). The underside of the top includes a retainer to assist in alignment. No glue or other fasteners are required. (4x4 posts not shown in picture above)</p>
		
<p>4A.. Have two people hold the sign as shown and slide the sign over the 4x4 posts and drop down into holes in top of monument base.</p>	<p>4B.</p>	<p>5A. Run a bead of construction adhesive (included) on top of sign board edges and place cap onto sign face. Be careful not to use too much adhesive and clean up any excess. Slide the sign cap back and forth and side to side to align it properly.</p>



5B.

6. This is what your sign will look like when completed. For added security you may wish to use a few large stainless pan head sheet metal screws and attach the 2 vertical upright posts to the wood treated 4x4's that are inside of it. You can place them on the outside or the inside of the post prior to attaching the top sign "cap".

For additional information:

EZSignsOnline.com